

POLARIS ATV FRONT GAS STRUTS

- Maintenance free gas strut
- Uses OEM spring
- Replaces stock hydraulic shock for better ride and performance
- Absorbs harsh riding conditions better than stock hydraulic shock



\$65.95 each

MODEL	FACTORY SPEC PART #	BRONCO PART #
250 2x4 1993	#530-502	#530-505
250 4x4 1993	#530-502	#530-505
250 6x6 1993	#530-502	#530-505
300 2x4 1994-95	#530-502	#530-505
300 4x4 1994-95	#530-502	#530-505
300 6x6 1994	#530-502	#530-505
350L 4x4 1993	#530-502	#530-505
350L 6x6 1993	#530-502	#530-505
400L 2x4 1994-95	#530-502	#530-505
400L 4x4 1994	#530-502	#530-505
400L 6x6 1994	#530-502	#530-505
Big Boss 1989	#530-502	#530-505
Big Boss 4x6 1989-92	#530-502	#530-505
Big Boss 6x6 1991-92	#530-502	#530-505
Euro 350L 4x4 1993	#530-502	#530-505
Euro 350L 6x6 1993	#530-502	#530-505
Euro Big Boss 6x6 1992	#530-502	#530-505
Euro Trail Boss 4x4 1992	#530-502	#530-505
Norwegian 400L 4x4 1994	#530-502	#530-505
Norwegian 400L 6x6 1994	#530-502	#530-505
Sport 400L 1994-95	#530-502	#530-505
Sportsman 4x4 1993-94	#530-502	#530-505
Swedish 400L 4x4 1994	#530-502	#530-505
Swedish 400L 6x6 1994	#530-502	#530-505
Trail Blazer 1990-95	#530-502	#530-505
Trail Boss 1989-99	#530-502	#530-505
Trail Boss 250 1988-92	#530-502	#530-505
Trail Boss 350L 2x4 1990-92	#530-502	#530-505
Trail Boss 350L 4x4 1990-92	#530-502	#530-505
Trail Boss 4x4 1989-92	#530-502	#530-505
ATP 500 4x4 2004	#530-500	#530-508
Sportsman 400 2004	#530-500	#530-508
325 Magnum 2x4 HDS 2000-02	#530-500	#530-508
325 Magnum 4x4 HDS 2000-02	#530-500	#530-508
325 Magnum 4x4 HDS II 2000	#530-500	#530-508
400L 6x6 1996	#530-500	#530-508
500 Magnum 4x4 HDS 2000-03	#530-500	#530-508
ATP 330 4x4 2004-05	#530-500	#530-508
ATP 500 4x4 2005	#530-500	#530-508
ATV Pro 500 4x4 PPS 2002	#530-500	#530-508
Big Boss 500 6x6 1998-99	#530-500	#530-508
Big Boss 6x6 400L 1995	#530-500	#530-508
Big Boss 6x6 400L 1997	#530-500	#530-508
Diesel 1999-01	#530-500	#530-508
Int'l Big Boss 2000	#530-500	#530-508
Int'l Big Boss 500 6x6 1999	#530-500	#530-508
Int'l Big Boss 6x6 2001-02	#530-500	#530-508
Int'l Diesel 1999	---	---
LUH 6x6 PPS 2002	#530-500	#530-508
Magnum 2x4 1995-98	#530-500	#530-508
Magnum 325 2x4 2000-02	#530-500	#530-508
Magnum 325 4x4 2000-02	#530-500	#530-508
Magnum 325 4x4 Freedom 2002	#530-500	#530-508
Magnum 325 4x4 Mose 2001	#530-500	#530-508
Magnum 330 2x4 2003-05	#530-500	#530-508

#530-500/508 (1 5/8" Diameter) - Replaces Polaris part numbers 2201460, 7041761, 7041755, 7041374

#530-502/505 (1 1/2" Diameter) - Replaces Polaris part numbers 7041451, 7041304, 7041211

BRONCO POLARIS ATV FRONT GAS STRUTS

- Maintenance free gas strut
- Complete assembly - includes strut, spring, retainer and bumper
- Spring is 10% stiffer than original
- Better ride than stock hydraulic struts



\$99.95 each

MODEL	FACTORY SPEC PART #	BRONCO PART #
Magnum 330 4x4 2003-06	#530-500	#530-508
Magnum 4x4 1995-98	#530-500	#530-508
Magnum 500 1999-02	#530-500	#530-508
Magnum 500 2x4 HDS 2002	#530-500	#530-508
Magnum 500 EB 2000	#530-500	#530-508
Magnum 500 RMK 2002	#530-500	#530-508
Magnum 6x6 1996-97	#530-500	#530-508
Norwegian 400L 6x6 1996	#530-500	#530-508
Norwegian Big Boss 500 6x6 '98	#530-500	#530-508
Norwegian Magnum 4x4 1995-98	#530-500	#530-508
PTV 4x4 Series 10	#530-500	#530-508
PTV 6x6 Series 10	#530-500	#530-508
Ranger 1999	#530-500	#530-508
Scrambler 1996	#530-500	#530-508
Scrambler 4x4 1995	#530-500	#530-508
Sport 400L 1996-98	#530-500	#530-508
Sportsman 335 1999-00	#530-500	#530-508
Sportsman 400 2001-03	#530-500	#530-508
Sportsman 400L 1997	#530-500	#530-508
Sportsman 4x4 1995-96	#530-500	#530-508
Sportsman 500 1996-00	#530-500	#530-508
Sportsman 500 2004	#530-500	#530-508
Sportsman 500 Duse 2001	#530-500	#530-508
Sportsman 500 Duse HO 2001	#530-500	#530-508
Sportsman 500 HO 2001	#530-500	#530-508
Sportsman 500 HO 2003	#530-500	#530-508
Sportsman 500 RSE 1999	#530-500	#530-508
Sportsman 500 RSE 2000	#530-500	#530-508
Sportsman 500 RSE HO 2001	#530-500	#530-508
Sportsman 600 2003-04	#530-500	#530-508
Sportsman 6x6 2000-07	#530-500	#530-508
Sportsman 6x6 MV	#530-500	#530-508
Sportsman 700 2002-04	#530-500	#530-508
Swedish Big Boss 500 6x6 1998	#530-500	#530-508
Swedish Magnum 4x4 1995-98	#530-500	#530-508
Swedish Magnum 6x6 1996-97	#530-500	#530-508
Swedish Sportsman 500 1996-98	#530-500	#530-508
Trail Blazer 1996-2001	#530-500	#530-508
Trail Blazer Freedom 2002	#530-500	#530-508
Trail Boss 2000-02	#530-500	#530-508
Trail Boss 325 SE 2001	#530-500	#530-508
Trail Boss 330 2003-07	#530-500	#530-508
Worker 335 1999	#530-500	#530-508
Worker 500 1999-01	#530-500	#530-508
Xpedition 325 2000-02	#530-500	#530-508
Xpedition 425 2000-02	#530-500	#530-508
Xplorer 1995	#530-500	#530-508
Xplorer 2000-01	#530-500	#530-508
Xplorer 300 1996-99	#530-500	#530-508
Xplorer 400 1999-02	#530-500	#530-508
Xplorer 400L 1996-98	#530-500	#530-508
Xplorer 4x4 2002	#530-500	#530-508
Xplorer 500 1997	#530-500	#530-508
Xpress 300 1996-99	#530-500	#530-508
Xpress 400 1996-97	#530-500	#530-508