



*"Setting the World's  
Performance Standards!"*

743 Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

## **SLP High Flow™ Air Horn Kit for 2007 Polaris 600/700 Cleanfire**

**Part #14-123**

### **Kit Contents:**

(3) 3/16" Rivets (1) Air Horn (16 1/2") Sealing Tape

**Read instructions completely and carefully before installing.**

1. Remove stock air horn from the under hood plenum.
2. Drill out the front existing hole to 3/16" (see illustration).
3. Align the SLP Air Horn with the long side towards the front of the sled so the hole drilled in step 2 matches the hole in the front of the air horn. Using the air horn as a guide drill the other two holes using a 3/16" drill bit.
4. Apply the supplied sealing tape to the flange of the air horn and rivet into place using supplied rivets.

**NOTE:** Air plenum needs to be removed to clean out all plastic shavings. Failure to do so can cause severe engine damage.

**IMPORTANT NOTE:** Do not modify stock air box, leave shelf and horn in place.

