



**Starting Line
Products, Inc.**

*"Setting the World's
Performance Standards!"*

743 Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

High Flow Air Horn Intake Kit for F Chassis Models

Part #14-292

Kit Contents:

- 1 - Air Horn
- 3 - Push Darts.

1. Remove stock bellows tube and bottom air horn from the air box.

Note: Pull and twist on the air horn to remove it.

2. Align the air horn over the existing hole in the air box and mark around the inside with a marker. Use extreme caution and cut around the marked line with a razor knife.

3. Using the air horn as a guide, drill three holes into the air box using an 11/64" drill bit. Fasten the air horn to the air box using 3 push darts provided.

4. Vacuum out all shaving's left from drilling and cutting.

5. Reinstall the stock bellows tube using the stock hose clamps.

