



*"Setting the World's
Performance Standards!"*

Starting Line Products, Inc.

743 Iona Rd. Idaho Falls, ID 83401, (208)529-0244 Fax (208)529-9000

M8 and M1000 High Flow™ Intake Kit

Part #14-299

Kit Contents:

- 1 - Intake Box
- 1 - 31" Sealing Tape
- 9 - 3/16" Plastic Rivets

Installation Instructions:

1. Remove stock bellows tube.
2. Cut out the provided pattern and tape it to the intake plenum at the front of the sled. Mark around the ***INSIDE*** of the pattern (see Illustration) then use extreme caution and cut around the marked line with a razor knife.
3. Install sealing tape on the top side of the SLP Intake box flange to seal the SLP Intake to the stock plenum.
4. Using the intake box as a guide align it to the intake plenum in the hood. Using 3/16" drill bit, drill one hole at a time and rivet into place working your way around the intake box.
NOTE: Make sure rivets are engaged in the stock plenum.
5. Vacuum out all shavings left from drilling and cutting.

