



*“Setting the World’s
Performance Standards”*

743 Iona Road • Idaho Falls, Idaho 83401 • Phone: (208) 529-0244 • Fax: (208) 529-9000

2001/02 XC 700/800 Edge Silencer P.N. 09-242

- 1)** Remove the stock silencer (retain all springs for silencer installation).
- 2)** Install the spring clip (provided) by first removing the top front bolt from the chaincase. Next, place the spring clip on the bolt and reinstall and torque to 8ft/lbs. The short side of the spring clip should be pointing to the engine.
- 3)** Place three strips of insulated heat tape (provided) on the side of the belly pan closest to the silencer, then cover using the strip of 30” reflective tape (provided).
- 4)** Install the SLP silencer using the stock silencer saddle and outlet hole. Spring into place using the OEM springs. For pipe to silencer connection, use the four SLP long springs.

NOTE: For best performance, we recommend that all connections (including pipe to cylinder) be sealed with a silicone sealer like Loctite 598 Ultra Black or equivalent. Use silicone to seal the silencer to the belly pan outlet hole.

Spring Tension Adjustment:

Spring loop adjustment is suggested for proper spring tension to prevent leakage and wear (low tension), allow adequate flex (proper tension) and prevent spring breakage (excessive tension).

When system is installed, the spring can be judged for proper tension. The winding spacing at the center of the spring will indicate tension. When proper, the two center windings will have .040” to .050” clearance between them. This is easily tested with a feeler gauge.

If tension is incorrect, the loop can be vent in the direction needed to increase or decrease tension. Attach a vise grip firmly to the loop and bend.

USE STOCK JETTING AND CLUTCHING

Caring for your ceramic coated pipes and/or silencer:

Ceramic Coating is an aluminum matrix applied to your exhaust system to provide a thermal barrier for more consistent performance. It is a coating which requires little maintenance to keep your pipes and/or silencer looking like new.

Upon completion of new installation, wipe the ceramic coated parts of the exhaust system down with brake cleaner. This will prevent oils and grease (usually in the form of fingerprints) from burning on and staining the exhaust during first initial startup.

To maintain your ceramic coated system, wash it with soap and water periodically (especially necessary after trailering it to and from your riding area on roads that have been treated with salt and other ice removing chemicals). Salt and other ice removing chemicals will attack and eat away at the ceramic coating. This will result in rust coming through the coating. Typically you will notice this rusting after your snowmobile has set for a period of time without the exhaust system being brought up to running temperature.

Periodically polish your ceramic coated pipes and/or silencer after each washing with an aluminum polish such as Mothers, Maas or Blue Magic aluminum polish that can be found at any automotive parts store. Do not use any acidic cleaners! For stubborn stains use fine 000 steel wool, then use a soft cloth with polish. Failure to maintain your ceramic coated pipes or silencer can result in damage to the ceramic coating for which there is no warranty coverage. A little care will insure that your pipes and/or silencer will continue looking like new for many years.

Note: In areas of the ceramic coated system where skin temperatures exceed 1300 degrees F, it is normal for the coating to turn dull gray. These areas should also be washed and polished periodically.