



SPARK PLUG INDEXING WASHERS

Part #245-500 and #245-510

Find the open end of the electrode on your spark plug. Put a small mark on the white porcelain part of the plug that corresponds with the open end of the electrode. Insert plug into head and tighten to 10 ft lbs of torque.

Notice which direction your mark faces once the plug is installed. If it is not facing the intake side, remove the plug, select one of the spark plug indexing washers and re-install the plug, tightening to 10 ft lbs. DO NOT remove the expansion washer from plug. Repeat installation procedure using different indexing washers until the electrode is facing directly at the intake indicated by your mark on the porcelain.

INDEXING WASHER SIZES: Gold - .030 Silver - .040 Blue - .050 Red - .060

Thank you for choosing HPE for your snowmobiling needs.