



‘SUPER SLIPPERY’ SLIDES Important “Break-In” Instructions

FOR ALL BRANDS: Drive your sled a few minutes until you feel the hi-fax begin to drag down your speed or require extra throttle to maintain a given speed. You will often notice a hot plastic smell when this occurs. If you do not understand the above condition, ask a friend or another experienced person to assist you.

WHEN HEAT DRAG OCCURS: **YOU MUST CHILL YOUR HI-FAX A RAPIDLY AS POSSIBLE.** This cannot be over emphasized. The best way to cool your hi-fax is to immediately pull over and hand pack them with snow. Another method is to pull into the powder snow and gently swerve from side to side at low speed to pack your track and suspension with snow. If your machine heat drags again, repeat the above process. Once will usually cause the hi-fax to thermal set. However, we have heard of conditions that took as high as three times. Failure to do this properly will cause premature wear.

Thank you for choosing HPE for your snowmobiling needs.