

POWERMADD[®] S.O.S. Universal 2-Quart

Mounting Instructions for S.O.S. Universal Part No. 14800-14803

READ ALL INSTRUCTIONS CAREFULLY PRIOR TO ASSEMBLY

TOOLS REQUIRED:

- 3/8" Socket Wrench
- Power Drill
- 3/16" Drill Bit

HARDWARE INCLUDED:

<u>Item</u>	<u>Qty</u>	<u>Description</u>
1	1	S.O.S. Universal
2	2	#14 Self-Threading Screws
3	2	Rubber Straps

POWERMADD'S 2-Quart S.O.S. was designed to mount in the engine compartment of snowmobiles that are equipped with a full metal bumper, although it can be mounted in any location where there is enough room and support. Be sure there is adequate clearance with any controls or rotating parts. The best location is to mount it to the bumper on the muffler side of the engine compartment. If there is not enough room on this side, mount the S.O.S. to the bumper on the clutch side of the engine compartment.

Step 1: After mounting location has been decided upon, locate any existing fasteners that can be used to mount the S.O.S. The most common is the 1/4-20 bolt at the end of the bumper that holds the belly pan to the footrest. Choose one of the slots in the S.O.S. that works best for your application and use the bumper bolt to mount one end of the S.O.S.

Step 2: Try to line up the other end of the S.O.S. with any existing bolts. If not, mark and drill a hole with a 3/16" drill bit through the first wall of the bumper only, from inside the engine compartment.

Step 3: Install one of the #14 self-threading screws provided from inside the engine compartment through the S.O.S. and into the bumper. You may want to install the second #14 screw through one of the slots in the center of the S.O.S. for added support.

NOTE: If your sled does not have a hollow bumper design, the #14 screws may protrude through the outside of the bumper and cause cosmetic or safety issues. In this case, you may have to provide your own fasteners, 1/4-20 bolts are preferred.

REMEMBER: S.O.S. also functions great for use in marine, truck, trailer, generator, recreational vehicle, 4x4 and other off-road vehicle applications. Simply use the basic mounting instructions as described above in these other applications.

LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. POWERMADD shall not be liable for damage or injury caused by defective materials or workmanship. POWERMADD may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.

POWERMADD[®]

1-800-435-6881

www.powermadd.com

PP5009 REV B