

POWERMADD® Universal CargoCaddy™

Installation Instructions for Part No. 13730

HARDWARE INLCUDED:

Qty	Description
1	CargoCaddy
3	Dividers
5	Foam Top Pads
1	Foam Bottom
1	Spare Belt Bracket
6	3/16" Pop Rivets

TOOLS REQUIERED:

Power Drill
7/32" Drill Bit
Pop Rivet Gun
Center Punch

OTHER AVAILABLE MODELS:

Part No.	Description
13731	Polaris Edge Chassis
13732	Arctic ZR Chassis, 2000 & newer (won't fit ZR 800 or ZR 900)
13733	Ski-Doo MXZ Chassis

WARNING: Read all instruction prior to installation. Never work on a snowmobile while snowmobile is running. Before any drilling is done to your snowmobile, take adequate precautions to be sure no debris will end up in your clutches or any other areas that may cause damage or injury. If possible, remove the clutch cover from the snowmobile while drilling any holes or doing any riveting, this will make installation easier.

STEP 1: Remove any previously installed spare spark plug or drive belt holders from the top of the clutch cover that will interfere with the CargoCaddy.

STEP 2: Drill through the CargoCaddy at the two circled bosses located on the bottom of the CargoCaddy using a 7/32" drill bit.



STEP 3: Place the CargoCaddy on top of the clutch cover and adjust its position so it does not interfere with the hood or any cooling or control mechanisms when closed. **NOTE: Hood foam above the CargoCaddy may need to be removed in some snowmobiles to allow proper closer of hood.**

STEP 4: With the CargoCaddy in the desired position on top of the clutch cover and the CargoCaddy lid opened or removed, use a center punch to mark drill locations in the clutch cover at the holes in the bottom of the CargoCaddy from **STEP 2**. Drill the holes in the clutch cover at the 2 locations using a 7/32" drill bit.

STEP 5: Place the CargoCaddy back on the clutch cover with the belt clip sandwiched between the CargoCaddy and the clutch cover. Using two rivets fasten the CargoCaddy and belt clip to the cover using the two previously drilled holes.

STEP 6: On the inside bottom of the CargoCaddy are 6 numbered bosses, pick 4 of them which you can drill through both the CargoCaddy and the clutch cover, and drill through using a 7/32" bit. Then use the 4 remaining rivets to fasten the CargoCaddy to the clutch cover.

STEP 7: Position each of the 5 top foam pieces to the underside of the CargoCaddy lid, between each of the 4 reference lines. Remove adhesive backer from each foam piece and affix to the lid. **NOTE: Adhesive cannot be repositioned.**

STEP 8: Place bottom foam liner into bottom of CargoCaddy and install dividers into desired positions.



LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. **POWERMADD** shall not be liable for damage or injury caused by defective materials or workmanship. **POWERMADD** may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.