



**Polaris Dragon RMK & Switchback (07 & newer)
Back Panel Vent Kit TSP-1255
Part #200-272**

1. Draw the outer edge of the OEM vent louver. Note, a Fine Tip Sharpie marker will work best.
2. Drill 2 side by side holes on the inner cut edge. This will be your starting cut point.
3. Use a jig saw to cut out the hole.
4. Clean and reconfigure the hole with a larger diameter bit in a die-grinder. This will give a smooth and clean finish to the hole. Then use a bur-knife and D-bur the inside and outside edge of the hole.
5. Hold the screen up into position and draw 5 rivet holes. Then remove the screen and center punch your marks. Then drill the holes with a 3/16" drill bit.
6. Install the screens using the provided pop rivets.

Should you have any problems during installation, please call (208) 691-5454