



## INSTALLATION INSTRUCTIONS Ultra-Light Plastic Ski Bottom

1. Remove wear bar from ski. inspect and replace if needed.
2. Drill out rivets attaching old plastic bottom to metal frame.
3. Unscrew and detach ski loop (skis with plastic loops only).
4. Remove plastic ski bottom from metal frame.
5. You may find it helpful to grind excess rivets off before punching inside.
6. You may empty old rivets from metal frame by removing ski loop or you may drill a 3/8 hole at the back bottom end of the metal frame.
7. Place new bottom on metal frame
8. Attach wear bar (to help align metal frame holes to plastic bottom).
9. If ski bottoms holes do not align exactly with the metal frame, you may need to drill new holes with a #11 drill bit (provided).
10. Reattach (plastic) ski loop.
11. Rivet new plastic bottom onto metal frame.

Thank you for choosing HPE for your snowmobiling needs.