



SLIDE HAMMER INSTRUCTIONS

Part #725-035

To use this tool for removing your slides, first elevate and secure the rear of the snowmobile. Remove the bolt or screw at the front of your slide rail. After doing this, spray the top edge of your old slides with lubrication (WD40 works well) and allow it to sit a few minutes.

Go to the exposed end of the slides through a track window and screw the tool into the slide being careful not to hit the aluminum rails. Using a sliding motion of the steel centerpiece, hammer the old slides off the rails.

The installation is essentially the same. Make sure to re-install the fastener at the front of the slides.

This tool will not work on some Ski Doo models as the hyfax is wider than the track window,

Thank you for choosing HPE for your snowmobiling needs.