



## INSTALLATION INSTRUCTIONS

### Grip Strips or Extenders

Items needed for installation: electric drill, 3/16" drill bit and rivet gun.

1. Position strip on top of tunnel roll. If needed, strip may be cut to proper length.
2. Hold strip securely, drill through strip and tunnel roll to place rivets near front and rear of strip. On long Grip Strips, more rivets may be added to hold strip securely. Rivet into place.
3. If you feel uncomfortable with installation, contact your dealer for proper installation. Buyers should have mechanical knowledge to install parts properly.
4. Grip Strips and Extenders are custom by nature, to be installed by buyer, and are sold without any express or implied warranty of merchantability or fitness for a particular purpose. HPE shall not be held liable for any special, incidental, or consequential damages, including damage, loss of revenue, cost purchased or use of this product.

Thank you for choosing HPE for your snowmobiling needs.