



## INSTALLATION INSTRUCTIONS

### Surefoot Grips

Items needed for installation: electric drill, 3/16" drill bit and rivet gun.

1. Position Surefoot near front of running board, locating where Surefoot fits best into running board taper.
2. **Warning: Do not drill holes through any re-enforcement brackets or through tunnel roll. On Polaris or Yamaha models with heat exchangers under the running boards, DO NOT drill into heat exchanger.** Hold Surefoot securely in place and drill mounting holes near the four outer corners of plate. **Note on Polaris and Yamaha models:** Drill outer holes near corners to miss heat exchangers and drill inner mounting holes into lip that extends up the tunnel.
3. Rivet into place using enclosed rivets.
4. If you feel uncomfortable with installation, contact your dealer for proper installation.
5. Surefoots are custom by nature, to be installed by buyer, and are sold without any express or implied warranty of merchantability or fitness for a particular purpose. HPE shall not be held liable for any special, incidental, or consequential damages, including damage, loss of revenue, cost purchased or use of this product.

Thank you for choosing HPE for your snowmobiling needs.