



INSTALLATION INSTRUCTIONS

Reed Spacers

1. Remove existing stock reed cage from engine.
2. Install spacer between reed cage and engine.
3. Install gaskets, to prevent air leaks, between metal surfaces.
4. Reinstall cage/manifold assembly on engine. Tighten manifold bolts. NOTE: bolts are threaded into aluminum, DO NOT over tighten and strip threads. Installation tip: when installing airbox, leave hose clamps on carb manifolds loose to allow extra movement. Tighten clamps after installation.
5. If you feel uncomfortable with installation, contact your dealer for proper installation. Buyers should have mechanical knowledge or experience to install parts properly.
6. Spacers are custom by nature, to be installed by buyer, and are sold without any express or implied warranty of merchantability or fitness for a particular purpose. HPE shall not be held liable for any special, incidental, or consequential damages, including damage, loss of revenue, cost purchased or use of this product.

Thank you for choosing HPE for your snowmobiling needs.