



Technical Tip #S1008

Torque Recommendations for Stud Installation

The torque recommendation for stud installation is:

Push-Through Studs	180 inch-lbs./15 ft-lbs.
T-Nut & Snap-Off	100-120 inch-lbs./8-10 ft-lbs.

After each ride, the torque should be checked.