

POWERMADD® Power-Lift Shield

Mounting Instructions for Part No. 15516

HARDWARE INCLUDED:

<u>Item</u>	<u>Qty</u>	<u>Description</u>
1	1	Shield
2	2	U-Bolt
3	4	Washer
4	4	Lock Nut

TOOLS REQUIRED:

7/16" Wrench

INSTRUCTIONS:

Place the shield on the Power-Lift as shown in the picture and install the u-bolts, washers and nuts. DO NOT over tighten the nuts as they will deform and bend the shield. Just snug them up until the shield is secured to the Power-Lift.



LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. POWERMADD shall not be liable for damage or injury caused by defective materials or workmanship.

POWERMADD may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.

POWERMADD®

1-800-435-6881

www.powermadd.com

PP5048 REV A