



Chain Tensioner #812-005

1. Install tensioner sprocket
2. Adjust tensioner so that you have 1/4" slack at top of chain at its tightest point.