

SLP Shock Tower Vent for Polaris IQ Chassis Right Hand Side Part # 32-526

Kit Contents:

6 - 3/16" Stainless Rivets 6 - Rivet Washers 1 - Perforated Metal Screen
1 - Template 1 - Inlet Grate


Installation Instructions

1. Place SLP Shock Tower vent on the outside of the shock tower and find where the vent best fits the contour of the bellypan. Using a marker mark around the outside edge of the vent.
2. Cut out paper template provided and tape it to the outside of the belly pan on the back side of the shock tower aligning it with the marks from step 1 (see illustration #1). Mark the *inside* of the template and cut out using a rotary tool and a multi-purpose cutting bit. Debur the holes.
3. Align the inlet grate with the areas cut out in step 1. Using the grate as a guide drill the 6 holes around the outer edge with a 3/16" drill bit.
4. Center the screen onto the inside of the belly pan over the six previously drilled holes and drill through the screen.
5. Place the grate on the outside of the belly pan and the screen on the inside and rivet into place using the 3/16" rivets and rivet washers provided.

Illustration #1



Template



SLP Hot Air Outlet for Polaris IQ Chassis Right Hand Side Part # 32-527

Kit Contents:

- 5 - Plastic Rivets
- 1 - Outlet Grate

Installation Instructions:

1. Remove right hand side panel.
2. Cut out paper template provided and align with the back of the side panel (see illustration). Using a marker trace around the inside of the template. Remove template and cut with a rotary tool and a multi-purpose cutting bit. Debur the hole.
3. Using the outlet grate as a guide align with the areas cut out in step 2 and drill with an 3/16" drill bit. Start at the top and drill one hole at the top and drill one hole at a time and install with the supplied plastic rivets and work your way down the grate.

Illustration #1



